

Product description/ Product number	For combination with	Picture	Drawing	Comment
HXM3-Adapter Nr. 6501.00145	MCDC3002 XX SC1801			For connecting the HXM3 flexboard directly into the Motion Controller